

The ComSource USB 60

Digital Message on Hold System

Installation & Users Guide



Introduction

The ***ComSource USB 60*** is a solid-state digital messaging system designed to play productions that require continuous message playback. Messages are stored on a removable USB flash drive. Message uploading is simple, just plug the USB flash drive into an available USB port on your computer, and then drop the MP3 file(s) onto the USB Drive.

The ComSource USB 60 features:

- **Message media: standard USB drive**
- **Controls: volume, 2 band equalizer, programmable message select**
- **Memory: Over 4 hours of audio at 32Kbps with included 64Mb USB drive.**
- **Visual interface: forward-facing LCD display**
- **Enclosure: metal**
- **Recording bitrate from: 8kbps up to 128Kbps**
- **Installation: easy-to-use wall mounting bracket**

Overview

Check to make sure you have all the following components:



Installation

-Because of the vast differences and complexity of many business telephone systems, we strongly recommend that you contact your telecom dealer to check compatibility, and aid with installation.

Wall Mounting: Mount the COMSOURCE USB 60 mounting bracket to a clean, dry surface using the screws supplied with your player.

Shelf Mounting: Apply the non-marring rubber feet to the bottom of the player.

Using the supplied audio cable connect the 600 ohm audio output on the digital player to the music on hold jack located on the key service unit.

Connect the AC wall transformer to the power jack on the digital player and plug the transformer into the wall outlet.

Insert MOH Flash Drive into the front of the COMSOURCE USB 60.

Press the power button. The audio will start playing in about 5 to 10 seconds. The audio may be previewed by turning the speaker on. Always turn speaker off for normal use.

Operation

Audio Adjustment

Volume: Use the UP or DOWN button on the front of the ComSource USB 60 player to adjust the volume to the desired level. *If the volume is set too high it may create distortion.*




MODE Now Playing
Generic Vol 056

EQ Control (Treble): From the main menu (Mode: Now Playing) Press the MODE button once and use the UP and DOWN arrow buttons to increase or decrease the treble, press the MODE button to save the setting or it will auto-save in 10 seconds.



MODE Treb Adjust
Generic To 00.0

EQ Control (Bass): From the main menu (Mode: Now Playing) Press the MODE button twice and use the UP and DOWN arrow buttons to increase or decrease the bass, press the MODE button to save the setting or it will auto-save in 10 seconds.



MODE Bass Adjust
Generic Bs 00.0

New Message Loading

Remove the USB FLASH DRIVE from the COMSOURCE USB 60 player. Insert the USB FLASH DRIVE into the USB port of any computer that contains the new message or messages to be transferred. *A USB extension cable is included. If needed, simply plug it into the USB port of your computer and Velcro the end to any convenient place.*

Double click on “My Computer”, double click on the MOH DRIVE to display its contents. If “MOH Drive” is not in the list, remove (wait 5 seconds) and re-insert the drive.


Delete any unwanted messages on the MOH DRIVE.

Drag and drop or copy and paste any new message file(s) to the MOH DRIVE.

Take the USB FLASH DRIVE back to the COMSOURCE USB 60 and insert the drive into the player. The new message will start playing in 5 to 10 seconds.


Message Control (optional)

If you wish to store multiple messages on the MOH Flash Drive: From the main menu (Mode: Now Playing) Press the mode button and hold, press the up arrow button and hold, release the mode button then release the up button. This procedure will take you to the message control menu.



MODE Bass Adjust
Generic Bs 00.0

Uses the down arrow button to scroll through the messages saved on your "MOH Drive" and locate the one you want to play. When located simply press the up arrow button once. This will change the message from mute to play.



MODE Bass Adjust
Generic Bs 00.0

You have now selected this message. In about 10 seconds the ComSource USB player will save your setting and start playing.